

**CEMENT > SPECIMEN PREPARATION** 

## **JOLTING TABLE**

Code: C125



- Used to compact cement mortar prisms in moulds.
- The 3-gang mould is placed on a table which is mounted above a cam rotating at 60 rpm.
- Equipped with digital cycle counter.
- The motor and gearbox assembly are enclosed in a protective housing; therefore, there are no moving parts in the body outside the housing.
- Mould is easily mounted and demounted.
- Noise-Reduction cabinet (C-125/SPC) can be purchased separately.

## **STANDARDS**

EN 196-1



## **TECHNICAL SPECIFICATIONS**

- $\bullet$  Used to compact 40 x 40 x 160 mm cement prisms in the moulds
- Digital Cycle Counter
- Rotating cam driven at 60 rpm
- Table drop height : 15 mm
- 220 240 V / 50 Hz

## **ORDERING INFORMATION**

ltem	Code
JOLTING TABLE	C125X00ET
JOLTING TABLE [60 Hz]	C125X00EK
SAFETY CABINET for JOLTING TABLE	C125P001H